

# S8003 Specification

## Accessories



## Installation Procedure



1



2

1. Insert the pulley into the five-star feet vertically 2. Insert the gas lift into the five-star feet vertically.



3



4

3. Unscrew the 4 screws from the base, align the tray with the holes on the base, and then tight the base by using the screws (Do not tight the screws before all the 4 screws are installed).

4. Install the T-shaped back bar: unscrew the screws on the back firstly, align the T-shaped back bar with the holes, and install the T-shaped back bar.



5. Installation Attention: T-frame There are pits Side up installation



6. Insert the round mouth of the tray at the head of the air rod. Sit on the chair and turn for a few turns to fasten automatically



7. Insert the back bar vertically into the tray  
**Attention: Do not rotate the regulator before insertion**



8. To place the backrest at the required height tighten the regulator  
**Back cushion gap and back rod depth related**



9. Install the armrests, after tightening the screws, install the screw cover  
**Please tighten the screws in turn after installing all the screws.**



① Angle adjusting lever ② Lifting lever

**This manual applies to all configurations  
for specific configurations please  
refer to your order.**