

3.2 Hold down the shrapnel of the Paddle Bar A and connect the Paddle Bar A with Paddle. (When connecting, please be careful about the shrapnel pointing at the hole of the Paddle.)



3.3 After the shrapnel pops out, clasp the buckle of the Paddle.



3.4 Connect Paddle Bar B with Paddle Bar A: insert the end (with the handle) of Paddle Bar B into the top of Paddle Bar A. The height can be adjusted depending on your needs.



3.5 Clasp the buckle to fix the whole paddle.



INFLATABLE PADDLE BOARD

PARTS LIST:



- | | | | |
|---------------|---------------------|-----------------|-----------------|
| 1. Air Pump | 2. Air Pump Hose | 3. Paddle Bar B | 4. Paddle Bar A |
| 5. Paddle | 6. Large Center Fin | 7. Backpack | 8. Coil Leash |
| 9. Repair bag | | | |

STEPS FOR ASSEMBLY:

1. Inflate the Paddle Board

1.1 Attach the hose to the pump



1.2 Turn anticlockwise the valve



1.3 Attach the hose to valve core, turn clockwise to lock



1.4 Inflating



2. Assemble the Large Center Fin on

2.1 Slide the fin in



2.2 Clip in to clock the fin



2.3 Locked



3. Paddle Assembling

Parts: Paddle, Paddle Bar A, Paddle Bar B



3.1 Unclasp the buckle of the Paddle.

