









# TR130

|   |  |   |  |   |  |
|---|--|---|--|---|--|
| <p>①</p>  <p>Casters<br/>QTY. 8</p>        | <p>②</p>  <p>T - bar<br/>QTY. 4</p> | <p>③</p>  <p>Outer hexagon screws<br/>QTY. 8</p> | <p>④</p>  <p>Pads<br/>QTY. 16</p> | <p>⑤</p>  <p>Outer hexagon nuts<br/>QTY. 8</p> | <p>⑥</p>  <p>Hexagon wrench with<br/>multi-holes<br/>QTY. 2</p> |
| <p>⑦</p>  <p>Adjusting foot<br/>QTY. 4</p> |  |   |  |   |  |



## Installation Steps:

1. Firstly, open the safety locks; then, stand the table legs on.
2. Put adjustable feet on the table legs.
3. Install on the casters ①
4. Put casters on the T-bar ②
5. Put T-bar over the table legs, then install Hexagon screw ③, pads ④ and hexagon nuts ⑤ individually. Locking Hexagon screws by Hexagon wrench with multi-holes ⑥