


# User Manual



# Contents


1 Riding Safety -----	02
2 Packing List -----	04
3 Diagram -----	04
4 Assembling Your Kick Scooter -----	05
5 First Ride -----	06
6 Charging -----	06
7 Learning to Ride -----	07
8 Warnings -----	08
9 LENZOD -----	11

# Thanks for choosing the Kickscooter

Thanks for choosing the Kickscooter

Your Kickscooter is a recreational product with mobile app, allowing you to connect with other riders

Enjoy your ride and connect with riders worldwide




## 1 Riding Safety

1. The Kickscooter is a recreational product Before mastering riding skills you need to is responsible for any injuries or damage caused by a riders inexperience or failure to follow the instructions in this document.
2. Please understand that you can reduce the risk by following all the instructions and warnings in this manual, but you cannot eliminate all the risks. Remember that whenever you ride the Kickscooter you risk injury from loss of control, collisions, and falls. When entering into public spaces always comply with the local laws and regulations As with other vehicles, faster speeds require longer braking distance. Sudden braking on low traction surfaces could lead to wheel slip or falls. Be cautious and always keep a safe distance between you and other people or vehicles when riding. Be alert and slow down when entering unfamiliar areas.
3. Always wear a helmet when riding. Use an approved bicycle or skateboard helmet that fits properly with the chin strap in place and provides protection for the back of your head
4. Do not attempt your first ride in any area where you might encounter children, pedestrians, pets, vehicles, bicycles, or other obstacles and potential hazards.
5. Respect pedestrians by always yielding the right of way. Pass on the left whenever possible. When approaching a pedestrian from the front, stay to the right and slow down. Avoid startling pedestrians. When approaching from behind announce yourself and slow down to walking speed when passing. Please obey local traffic laws and regulations if situation is different.

6. In places without laws comply with the safety guidelines outlined in this manual, Inc. is not responsible for any property damage, personal injury/death, accidents, or legal disputes caused by violations of the safety instructions.
7. Do not allow anyone to ride your Kickscooter on his/her own unless they have carefully read this manual and followed the New Rider Tutorial in the App. The safety of new riders is your responsibility. Assist new riders until they are comfortable with the basic operation of the Kickscooter, Make sure each new rider wears a helmet and other protective gear.
8. Before each ride check for loose fasteners and damaged components. If the Kickscooter makes abnormal sounds or signals an alarm, immediately stop riding Diagnose your Kickscooter via the App and call your dealer/distributor for service
9. Be alert! Scan both far ahead and in front of your Kickscooter-your eyes are your best tool for safely avoiding obstacles and low traction surfaces(including but not limited to, wet ground, loose sand, loose gravel, and ice).
10. To reduce risk of injury, you must read and follow all "CAUTION and WARNING notices in this document. Do not ride at an unsafe speed. Under no circumstance should you ride on roads with motor vehicles. The manufacturer recommends riders be 14+ years old. Always follow these safety instructions.
  - A. People who should not ride the Kick Scooter include
    - i Anyone under the influence of alcohol or drugs
    - i. Anyone who suffers from disease that puts them at risk if they engage in strenuous physical activity
    - ii. Anyone who has problems with balance or with motor skills that would interfere with their ability to maintain balance
    - v Anyone whose weight is outside the stated limits (see Specifications)
    - v Pregnant women
  - B. Riders under the age of 18 years old should ride under adult supervision
  - C. Comply with local laws and regulations when riding this product. Do not ride where prohibited by local laws
  - D. To ride safely, you must be able to clearly see what is in front of you and you must be clearly visible to others
  - E. Do not ride in the snow, in the rain, or on roads which are wet, muddy icy, or that are slippery for any reason  
Do not ride over obstacles (sand, loose gravel, or sticks). Doing so could result in a loss of balance or traction and could cause a fall
11. Do not attempt to charge your Kickscooter if, the charger, or the power outlet is wet
12. As with any electronic device, use a surge protector when charging to help protect your Kickscooter from damage due to power surges and voltage spikes Only use the Segway supplied charger. Do not use a charger from any other different product models
13. Use only approved parts and accessories. Do not modify your Kickscooter, Modifications to your Kickscooter could interfere with the operation of the Kickscooter, could result in serious injury and/or damage, and could void the Limited Warranty.


# 2 Packing List

## Assembled Kick Scooter




## Accessories

Manual x 1



Key x2



Fuse




Screw x4



Allen Wrenchx2



Charger x1





When unpacking your Kickscooter, please verify that the above items are included in the package. If you are missing any components, please contact your dealer/distributor or nearest service center.

After verifying that all components are present and in good condition you can assemble your new Kickscooter

Please retain the box and packaging materials in case you need to ship your Kickscooter in the future

Remember to power off your Kickscooter and unplug the power card before assembling mounting accessories, or cleaning the mainframe


# 3 Diagram



## REMOVABLE BATTERY


1. Before unlock/lock, Make sure fold the scooter
2. Unlock: Insert the key, rotate 360° clockwise, make sure taken the key out first, then take out the battery.
3. Lock: put the battery back, insert the key, rotate 360° counter clockwise.

## Dashboard & Power Button




## 4 Assembling Your Kickscooter


1. Unfold the handlebar stem and fasten it. Then unfold the kickstand to support the Kickscooter.




2. Firmly connect the wires inside the handle and the stem. Slide the handle onto the stem. Be aware of the correct orientation.



3. Install six screws (two on each side) with the included hex wrench.



4. Verify that your Kickscooter can be powered on and off.



## 5 First Ride




▲ There are safety risks when learning to ride the Kickscooter, You must read the Riding Safety via the App before your first ride.

For your safety, your new Kickscooter is not activated and will beep occasionally after Power ON.


Until activated, the Kickscooter maintains very low riding speed, and cannot be ridden with full function. Install the App on your mobile device (with Bluetooth 4.0 or above), connect to the Kickscooter with Bluetooth, and follow the App instructions to activate your KickScooter and enjoy the full performance

App Scan the QR code to download the App.

- 1 Install the App and register/login.




- 2 Power on the Kickscooter. A blinking Bluetooth icon indicates the Kickscooter is waiting for a connection.




- 3 Click "Vehicle"- Scan for Vehicle"to connect to your Kickscooter.

The Kickscooter will beep when the connection is successful. The Bluetooth icon will stop blinking and remain illuminated



- 4 Follow the App instructions to activate the Kickscooter and learn how to ride safely  
You can now start to use your Kickscooter, check the status with App, and interact with other users. Have fun!

## 6 Charging




### Charging step tips



Open the charge port cover.



Insert the charge plug.



Close the charge port cover when finished.

### ▲ WARNING

Do not charge if the charge port or power cord is wet.


Do not charge or use your battery if it is damaged or see trace of water.

Close the charge port cover when not charging.


## 7 Learning to Ride




Wear an approved helmet and other protective gear to minimize any possible injury.



1. Power on the Kickscooter and check the power level indicator. Charge the Kickscooter if the battery level is low.




2. Stand on the footrest with one foot and push off with another foot to start gliding.




3. Put your other foot on the footrest to keep both feet stable. Press the throttle on the right hand to speed up when you are balanced.

Note, for your safety, the motor will not engage until the Kickscooter reaches 1.86 mph (3 km/h).



4. Slow down by releasing the throttle: and brake by squeezing the brake lever.



5. To turn, shift your body weight and turn the handle slightly.

### ⚠ WARNING

When hard braking, you risk serious injury due to loss of traction and falls. Maintain a moderate speed and look out for potential hazards.




# 8 Warnings


**WARNING**  
Failure to follow these instructions could lead to serious Injury.




! DO NOT ride the Kickscooter in the rain.  
DO NOT get wet.





! DO NOT ride over speed bumps, thresholds, or other bumps at HIGH SPEED.



! Watch your head when passing through doorways.




! Do not keep your feet on the rear fender.




! DO NOT press the throttle when walking with the Kickscooter.




! Avoid contacting obstacles with the tire/wheel.




! DO NOT carry heavy objects on the handlebar.



! DO NOT ride the Kick scooter with only one foot.




! DO NOT ride on public roads, motorways, or highways.




! DO NOT rotate the handle violently while driving at high speed



! DO NOT ride through puddles or other bodies of water.




! The Kick scooter is for one rider only. Do not carry any passengers. Do not carry a child. Do not ride when pregnant.



! DO NOT touch the hub motor after riding because it can get hot.



! DO NOT take your hands off the handlebar while riding. Do not ride with one hand only.



**!** DO NOT ride up and down stairs or jump over obstacles.



**!** Do not use mobile phone or wear earphones when operating the Kickscooter.

#### **⚠ WARNING**

Always keep both hands on the handlebar or you risk serious injury due to loss of balance and falls.



WEEE Disposal and Recycling Information Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Battery recycling information for the European Union



Batteries or packaging for batteries are labeled in accordance with European Directive 2006/66/EC and amendment 2013/56/EU concerning batteries and accumulators and waste batteries and accumulators. The Directive determines the framework for the return and recycling of used batteries and accumulators as applicable throughout the European Union. This label is applied to various batteries to indicate that the battery is not to be thrown away, but rather reclaimed upon end of life per this Directive

In accordance with the European Directive 2006/66/EC and amendment 2013/56/EU, batteries and accumulators are labeled to indicate that they are to be collected separately and recycled at end of life. The label on the battery may also include a chemical symbol for the metal concerned in the battery (Pb for lead, Hg for mercury and Cd for cadmium). Users of batteries and accumulators must not dispose of batteries and accumulators as unsorted municipal waste, but use the collection framework available to customers for the return, recycling, and treatment of batteries and accumulators. Customer participation is important to minimize any potential effects of batteries and accumulators on the environment and human health due to the potential presence of hazardous substances

Before placing electrical and electronic equipment (EEE) in the waste collection stream or in waste collection facilities, the end user of equipment containing batteries and/or accumulators must remove those batteries and accumulators for separate collection

# APPLICATION DOWNLOAD

Search LENZOD on app store or scan the QR code to download the APP and install.

